

OPERATION MANUAL

VISITOR PANEL

麗業科技開發有限公司

Treasure Business Technology Development Ltd

CONTENTS

A.	Main interface	2
B.	Resident.....	3
C.	Visitors call	4
D.	Property Management office.....	5



A. Main interface

This interface has three function buttons, which are:

1. **Resident:** Press the code to unlock the lock.
2. **Visitors Call:** Enter the floor, room number and call the residents.
3. **Concierge:** Call Customer Service for assistance



Figure 1

B. Resident

Enter a 4-digit code to unlock the Main Entrance.




Figure 2

C. Visitors call

Enter the floor number on the left and the room number on the right, and press < Call > to call the residents of the corresponding unit. After the resident authorizes entry, a ticket will be printed out at the printer, which the QR code on the ticket can be used to scan to open the main entrance.

If the QR code scanning fails, or the server cannot be verified, an error box will pop out, please contact the concierge. If the scanning success, the main entrance door will open and you can enter.




Figure 3

D. Property Management office

When you forget your password and cannot print the QR code to open the door, you can press the < **Concierge** > to contact concierge for assistance.



Figure 4